



www.McBayPerformance.com
1-877-337-4177

REAR COIL SPRING SPACER

MP1601T / MP1602T / MP1603T / MP1604T / MP1605T / MP1606T

TRUCKS & SUVs / INSTALLATION INSTRUCTIONS

1 / REMOVE

1. Raise the vehicle and support it securely with jack stands.
2. Support the rear axle, for example with a floor jack under the differential.
3. Remove the shock absorber lower mounting bolts.
4. Remove the sway bar link bolts.
5. Remove the bolts and brackets that secure the coil springs to the axle.
6. Slowly lower the rear axle with the jack.
7. Remove the rear coil springs.

2 / INSTALL

1. Place the rear coil spring spacer on the axle with the small hole facing up.
2. Place one rear coil spring on top of the spacer (photo 1).
3. Install the included bolt and washer and the factory hold-down bracket onto the spring and spacer (photo 2).
4. Add the lock washer and nut, then tighten to the manufacturer's specifications.
5. Repeat steps 1-4 for the other spring.
6. Slowly raise the rear axle, making sure the tops of the springs seat back in place.
7. Install the shock absorber lower mounting bolts and tighten them to the manufacturer's torque specifications.
8. Reconnect the sway bar link bolts.
9. Remove the rear axle support.
10. Slowly lower the vehicle.
11. Bounce the rear of the vehicle (jounce), then take it for a test drive.

TRUCK / SUV APPLICATIONS

CHEVROLET

1969-1972 Blazer
1967 C10 Panel
1963-1972 C10 Pickup
1963-1972 C20 Pickup
1967-1972 C10 Suburban
1967-1972 C20 Suburban

GMC

1970-1972 Jimmy
1967-1972 C15 Pickup
1967-1972 C25 Pickup
1967-1972 C15 Suburban
1967-1972 C25 Suburban
1967-1972 P15 Van



1 / Spring on spacer



2 / Hold-down hardware

IMPORTANT NOTES

Protect the spring coating

Handle coil springs carefully to avoid chipping or scratching the coating. Coating damage will cause premature coil spring failure.

When reinstalling springs

Reuse the upper rubber coil insulator between the vehicle and the spring when reinstalling the springs.

Shock length

2" (MP1604T), 2.5" (MP1606T) and 3" (MP1605T) spacer sets may require extended rear shocks or shock extenders (not included).

SPACER SIZE / STATED LIFT

MP1601T	MP1602T	MP1603T	MP1604T	MP1606T	MP1605T
0.5" spacer / 0.5" lift	1.0" spacer / 1.0" lift	1.5" spacer / 1.5" lift	2.0" spacer / 2.0" lift	2.5" spacer / 2.5" lift	3.0" spacer / 3.0" lift

WARRANTY: Spacers are warranted against manufacturing defects for the life of the vehicle. The warranty does not cover spacer damage due to improper installation or use. Warranty refunds are limited to the original order cost. Labor and any other costs incurred are not covered.

DISCLAIMER: McBay Performance, Inc. is not responsible or liable for damage to vehicles or property, or injury to persons, during installation, removal or use of the product.