



MP1601, MP1602, MP1603, MP1604, MP1605, MP1606 REAR COIL SPRING SPACER INSTALLATION INSTRUCTIONS

REMOVAL PROCEDURE:

1. Raise and support the vehicle securely with jack-stands.
2. Install the rear axle support such as a floor jack under the differential.
3. Remove the shock absorber lower mounting bolts.
4. Remove sway bar link bolts.
5. Remove the bolts and brackets that hold down the coil spring to the axle.
6. Slowly lower the rear axle with the jack.
NOTE: Use care when handling the coil springs in order to avoid chipping or scratching the coating. Damage to the coating will result in premature failure of the coil springs.
7. Remove the rear coil springs.

INSTALLATION PROCEDURE:

1. Install rear coil spring spacer onto the the axle small hole side up.
2. Install one rear coil spring on top of the spacer (see photo 1).
3. Insert included bolt & washer and factory hold-down bracket onto the spring and spacer (see photo 2).
4. Add lock washer and nut and tighten down to manufacturers specs.
5. Repeat 1-4 for other spring.



6. Slowly raise the rear axle and make sure the top of the springs mount back into place.
7. Install the shock absorber lower mounting bolts and tighten bolts to manufacturers torque specs.
8. Reconnect sway bar link bolts.
9. Remove rear axle support.
10. Slowly lower the vehicle.
11. Jounce rear of vehicle and take for a test drive.
NOTE: 2" (MP1604), 2.5" (MP1606) & 3" (MP1605) tall spacer sets may need rear extended shocks or shock extenders after installation (not included).

SPACER PART NUMBERS & SIZES

- MP1601 – 0.5" (gives 1/2" of lift)
- MP1602 – 1.0" (gives 1" of lift)
- MP1603 – 1.5" (gives 1-1/2 of lift)
- MP1604 – 2.0" (gives 2" of lift)
- MP1606 – 2.5" (gives 2-1/2" of lift)
- MP1605 – 3.0" (gives 3" of lift)

CAR APPLICATIONS

CHEVROLET
1961-1964 Electra
1965-1966 Gran Sport
1961-1963 Invicta
1961-1964 LeSabre
1963-1965 Riviera
1964-1966 Skylark
1964-1966 Special
1963-1964 Wildcat
CHEVROLET
1964-1966 Chevelle
1964-1966 El Camino
1964-1966 Malibu
OLDSMOBILE
1965-1966 442
1964-1966 Cutlass
1964-1966 F-85
1961-1966 Starfire
1958-1964 Super 88
1964-1966 Vista Cruiser
PONTIAC
1958-1964 Bonneville
1958-1964 Catalina
1962-1964 Grand Prix
1964-1966 GTO
1964-1966 LeMans
1959-1964 Starchief
1964-1966 Tempest
1960-1961 Ventura

TRUCK APPLICATIONS

CHEVROLET
1969-1972 Blazer
1967 C10 Panel
1963-1972 C10 Pickup
1963-1972 C20 Pickup
1967-1972 C10 Suburban
1967-1972 C20 Suburban
GMC
1970-1972 Jimmy
1967-1972 C15 Pickup
1967-1972 C25 Pickup
1967-1972 C15 Suburban
1967-1972 C25 Suburban
1967-1972 P15 Van

WARRANTY: Spacers are warranted from manufacturers defects for the life of the vehicle. Warranty does not cover damage to spacers due to improper installation or use. Refunds for warranty issues will consist of original order cost only and do not cover any labor costs or any other costs that were incurred.

DISCLAIMER: McBay Performance, Inc. is not responsible or liable for any damage to vehicle, property or persons when product is being installed, removed or in use.