



MP1614, MP1615, MP1616, MP1617, MP1618 REAR COIL SPRING SPACER INSTALLATION INSTRUCTIONS

REMOVAL PROCEDURE:

1. Raise and support the vehicle securely with jack-stands.
2. Install the rear axle support such as a floor jack under the differential.
3. Remove the shock absorber lower mounting bolts.
4. Remove sway bar link bolts.
5. Remove the bolts and brackets that hold down the coil spring to the axle.
6. Slowly lower the rear axle with the jack.

NOTE: Use care when handling the coil springs in order to avoid chipping or scratching the coating. Damage to the coating will result in premature failure of the coil springs.

7. Remove the rear coil springs.

INSTALLATION PROCEDURE:

1. Install rear coil spring spacer onto the the axle tapered lip side up.
2. Install one rear coil spring on top of the spacer.
3. Repeat for other side.

NOTE: Reuse upper rubber coil insulator between car & spring when putting springs back in place.

4. Slowly raise the rear axle and make sure the top of the springs mount back into place.
5. Install the shock absorber lower mounting bolts and tighten bolts to manufacturers torque specs.
6. Reconnect sway bar link bolts.
7. Remove rear axle support.
8. Slowly lower the vehicle.
9. Jounce rear of vehicle and take for a test drive.

NOTE: 2" (MP1617), 2-1/2" (MP1614) & 3" (MP1618) tall spacer sets may need rear extended shocks or shock extenders after installation (not included).

SPACER PART NUMBERS & SIZES

- MP1615 – 1.0" (gives 1" of lift)
- MP1616 – 1.5" (gives 1-1/2" of lift)
- MP1617 – 2.0" (gives 2" of lift)
- MP1614 – 2.5" (gives 2-1/2" of lift)
- MP1618 – 3.0" (gives 3" of lift)

CAR APPLICATIONS	
FORD	
1972-1974 Country Sedan	
1966-1977 Custom / Custom 500	
1975-1976 Elite	
1966-1974 Galaxie / Galaxie 500	
1972-1976 Gran Torino	
1966-1978 LTD	
1977-1979 LTD II	
1972-1979 Ranchero	
1967-1979 Thunderbird	
1972-1976 Torino	
LINCOLN	
1970-1979 Continental	
1969-1971 Mark III	
1972-1976 Mark IV	
1977-1979 Mark V	
MERCURY	
1967-1968 Colony Park	
1974-1979 Cougar	
1975-1978 Grand Marquis	
1969 Marauder	
1967-1978 Marquis	
1966-1968 Montclair	
1972-1976 Montego	
1965-1974 Monterey	
1966-1968 Parklane	

WARRANTY: Spacers are warranted from manufacturers defects for the life of the vehicle. Warranty does not cover damage to spacers due to improper installation or use. Refunds for warranty issues will consist of original order cost only and do not cover any labor costs or any other costs that were incurred.

DISCLAIMER: McBay Performance, Inc. is not responsible or liable for any damage to vehicle, property or persons when product is being installed, removed or in use.