

MP2007, MP2008, MP2009 & MP2010 REAR COIL SPRING SPACER LIFT INSTALLATION INSTRUCTIONS



WARNING: BEFORE INSTALLING, PLEASE READ INSTRUCTIONS CAREFULLY. NOT FOLLOWING THESE INSTRUCTIONS CAN RESULT IN PROPERTY DAMAGE OR SERIOUS INJURY.

1. Jack up frame of the car and place on jack stands or secure blocks. **DO NOT** work under the vehicle while it is being held up by the jack alone.
2. Remove the rear wheels.
3. Support the rear axle with a jack so it will not fall.
4. Remove both lower shock mounting bolts.
5. Remove both quad shocks that are above and to the right of the brake drum/rotor (Mustang only if equipped).
6. Slowly lower the axle making sure not to over extend any brake lines.
7. Reach in and remove coil spring and remove rubber isolator (if equipped).
8. **For Lift Spacer Top Placement Vehicles** (see application chart) install lift spacer on top of coil spring with raised side facing into the coil spring (see Figure 1 & Figure 2).
9. Install rubber isolator on top of coil spring spacer (if equipped).
10. **For Lift Spacer Bottom Placement Vehicles** (see application chart) install lift spacer on top of coil spring axle perch and place coil spring on top of lift spacer with the raised part of the lift spacer facing up inside the coil spring.
11. Reinstall spring and make sure coil spring, lift spacer and rubber isolators (if equipped) are seated properly in place.
12. Slowly raise axle (making sure not to lift vehicle off of jack stands) and reconnect quad shocks (Mustang only if equipped).
13. Reinstall lower shock mounting bolts but do not fully tighten yet.
14. Install rear tires and torque lug nuts to manufacturers specs.
15. Take out jack stands and slowly lower vehicle to the ground.
16. Tighten lower shock mounts to manufacturers torque specs.

APPLICATIONS	PLACEMENT
BUICK	
1986-1999 LeSabre	Bottom
1979-1985 Riviera	Top
CADILLAC	
1979-1985 Eldorado	Bottom
1976-1979 Seville	Bottom
CHEVROLET	
1995-1996 Corsica	Top
FORD	
1978-1983 Fairmont	Top
1981-1982 Granada	Top
1983-1986 LTD	Top
1979-2004 Mustang	Top
1980-1988 Thunderbird	Top
LINCOLN	
1984-1992 Mark VII	Top
1982-1987 Continental	Top
MERCURY	
1979-1986 Capri	Top
1980-1988 Cougar	Top
1983-1986 Marquis	Top
1978-1983 Zephyr	Top
OLDSMOBILE	
1992-1999 88	Bottom
1979-1985 Toronado	Top
PONTIAC	
1987-1999 Bonneville	Bottom

SPACER PART #'s & LIFT AMOUNTS

- MP2007 – 0.5" (gives 1/2" of lift)
- MP2008 – 1.0" (gives 1" of lift)
- MP2009 – 1.5" (gives 1-1/2" of lift)
- MP2010 – 2.0" (gives 2" of lift)

WARRANTY: Spacers are warranted from manufacturers defects for the life of the vehicle. Warranty does not cover damage to spacers due to improper installation or use. Refunds for warranty issues will consist of original order cost only and do not cover any labor costs or any other costs that were incurred.

DISCLAIMER: McBay Performance, Inc. is not responsible or liable for any damage to vehicle, property or persons when product is being installed, removed or in use.

Figure 1



Figure 2

