

## Front Camber Guide & Cam Kit Installation Instructions

1. Inspect vehicle for loose or worn parts and abnormal tire wear patterns.
2. Check alignment to determine amount of camber change needed.
3. Raise and support the front of the vehicle by the frame.
4. Loosen the lower control arm nut (see figure 1)
5. Install camber guide with supplied 1/4" x 1" bolt. Install cam nut and and snug, but do not tighten at this time. (See figure 2)
6. Watching your alignment readings, adjust camber to the manufacture's specifications by turning cam nut until the needed adjustment is achieved.
7. Torque cam bolt kit to manufacture's specifications.
8. Repeat procedures for the other side of the vehicle.
9. Proceed with the alignment and road test vehicle.



Figure 1



Figure 2