

Factory Replacement Cam Bolt Kit

1. Perform pre-alignment check in normal manner, check for loose or worn parts.
2. Raise front of vehicle safely by frame.
3. Remove and replace alignment cam bolts one at a time.
4. Snug the nut but do not tighten at this time.
5. Watching your alignment readings, adjust cams until needed adjustment is achieved.
6. Torque nuts to manufacturer's specifications.
7. Proceed with alignment and road test vehicle.