

Rear Pivot Bushing with Cam Bolts Installation Instructions

1. Remove the ^{arm} from the car following OE procedures
2. Press out the old pivot bushing with the use of the ball joint press tool
3. Install new pivot bushing using ball joint universal adaptor set or aftermarket press kit. Note: make sure your press on the outer ring to avoid damage to pivot bushing or boot
4. Press bushing until it is centered in the arm
5. Install new cam bolt if needed, and reinstall arm
6. Finish adjusting alignment to specifications
7. Torque all bolts to manufacturer's specifications
8. Finish alignment and road test vehicle

1996 A

95-289-0613

